

1501 Pomona Rd, Corona, CA 92878 • 951.279.6655 • racetech.com

## TFCW 50H WP DUAL CHAMBER FORK CAP WRENCH

<IP TFCW 50H> M. Wiley 5/30/07

Recommended Tools: TMVJ 065 Vise Jaws, TFPC 2328 Piston Ring tool, TSNN 01 Nitrogen Needle, TSNG 02 Nitrogen Gauge.

- 1. Remove compression adjuster knob.
- 2. Remove Phillips Head Screw to access Nitrogen Valve, release nitrogen pressure using TSNN 01 Nitrogen Needle.
- 3. Remove outer fork cap (50mm) first then inner cap (slotted) can also be removed. Inner cap can be removed later if preferred while holding the cartridge in the TMVJ 065 soft jaws.
- 4. Complete fork service & reassembly as needed per the manufactures instructions & specs, consult your service manual.
- 5. Use the TSNN 01 Nitrogen Needle & TSNG 02 Nitrogen Gauge to set pressure to WP/KTM Specs.





